EVEREST


- Calculate single door leaf size
- Calculate double door leaf size
- Check obstructions
- Installation requirements

Calculate single door leaf size


Step1: Measure fully finished doorway





Step2: Calculate maxiumum rectangular surface




Step3: Calculate door leaf size











Calculate double door leaf size




Step1: Measure fully finished doorway

Step2: Calculate maxiumum rectangular surface





Step3: Calculate door leaf size





Check obstructions





Installation requirements

